



## 3089-03

<b>OVERALL</b>	w88 D36 H37
<b>INSIDE</b>	w80 D22 H17
<b>SEAT HEIGHT</b>	18
<b>ARM HEIGHT</b>	23
<b>BACK RAIL HEIGHT</b>	37
<b>STANDARD WITH</b>	Welt Small Nail Head on Out-Arm and Out-Back Panels (3) 12x28 Down Back Bolsters Cushion - naturalLEE
<b>SHOWN WITH</b>	Shown without Standard Nail Head Trim on Outarm & Outback