



## 1211-03

**OVERALL** w93 D37 H38  
**INSIDE** w86 D21 H19  
**SEAT HEIGHT** 18  
**ARM HEIGHT** 24  
**BACK RAIL HEIGHT** 38  
**STANDARD WITH** Welt  
Down Backs  
Cushion - naturalLEE

Same frame as 1011-03, Back Cushions  
are 3-Inches Higher