



## 1011-03

<b>OVERALL</b>	W93 D37 H38
<b>INSIDE</b>	W86 D21 H19
<b>SEAT HEIGHT</b>	18
<b>ARM HEIGHT</b>	24
<b>BACK RAIL HEIGHT</b>	38
<b>STANDARD WITH</b>	Welt Down Backs Cushion - naturalLEE

Same frame as 1211-03, Back Cushions  
are 3-Inches Lower