



**C3972-01**  
SG SW



**L3973-01**

**3972-01 CHAIR**

OVERALL W33 D38 H36 SEAT H17  
INSIDE W23 D21 H18 ARM H22  
BACK RAIL HEIGHT 31  
STANDARD WITH TOPSTITCHING



**3972-00 OTTOMAN** W27 D21 H15

**3973-01 CHAIR**

OVERALL W33 D38 H36 SEAT H17  
INSIDE W23 D21 H18 ARM H22  
BACK RAIL HEIGHT 31  
STANDARD WITH TOPSTITCHING



**3973-00 OTTOMAN** W27 D21 H15



**C1601-01**  
SG SW

**3974-01 CHAIR**

OVERALL W33 D38 H37 SEAT H19  
INSIDE W23 D21 H18 ARM H23  
BACK RAIL HEIGHT 32  
STANDARD WITH TOPSTITCHING



**3974-00 OTTOMAN** W27 D21 H15

**1601-01 CHAIR**

OVERALL W29 D36 H35 SEAT H18  
INSIDE W20 D21 H18 ARM H22  
BACK RAIL HEIGHT 30  
STANDARD WITH TOPSTITCHING



**1601-00 OTTOMAN** W23 D18 H16



**L3063-01**



**L3163-01**

**3063-01 CHAIR**

OVERALL W33 D39 H35 SEAT H18  
INSIDE W23 D23 H16 ARM H23  
BACK RAIL HEIGHT 31  
STANDARD WITH TOPSTITCHING



**3063-00 OTTOMAN** W31 D25 H17

**3163-01 CHAIR**

OVERALL W33 D39 H35 SEAT H18  
INSIDE W23 D23 H16 ARM H23  
BACK RAIL HEIGHT 31  
STANDARD WITH TOPSTITCHING



**3163-00 OTTOMAN** W31 D25 H17