



1071-01 CHAIR

OVERALL W34 D40 H37 SEAT H18
 INSIDE W20 D21 H20 ARM H22
 BACK RAIL HEIGHT 33

SG SW



1071-00 OTTOMAN W31 D21 H17



1074-01 CHAIR

OVERALL W34 D40 H37 SEAT H18
 INSIDE W20 D21 H20 ARM H22
 BACK RAIL HEIGHT 33

SW



1074-00 OTTOMAN W31 D21 H17



L1074-01

SW



C1074-01

SG SW



1180-01 CHAIR

OVERALL W34 D40 H39 SEAT H18
 INSIDE W20 D21 H23 ARM H22
 BACK RAIL HEIGHT 34

SG SW



1180-00 OTTOMAN W31 D21 H17



C1180-01

SG SW



1077-01 CHAIR

OVERALL W31 D39 H34 SEAT H17
 INSIDE W20 D22 H20 ARM H22

ALSO AVAILABLE

1077-41 CHAIR

OVERALL W34 D40 H35 SEAT H18
 INSIDE W22 D22 H21 ARM H22



1077-00 OTTOMAN W31 D21 H17



1077-41



3577-01 CHAIR

OVERALL W36 D42 H36 SEAT H18
 INSIDE W24 D25 H21 ARM H22
 BACK RAIL HEIGHT 32



3577-00 OTTOMAN W31 D21 H17



3477-01 CHAIR

OVERALL W36 D42 H36 SEAT H18
 INSIDE W24 D22 H18 ARM H22
 BACK RAIL HEIGHT 30

OPTIONAL TOPSTITCHING ON SEAT AND BACK CUSHION
 OPTIONAL BANDING AND JUMBO NAIL HEAD



3477-00 OTTOMAN W31 D21 H17



L3477-01