



1071-01 CHAIR

OVERALL W34 D40 H37 SEAT H18
 INSIDE W20 D21 H20 ARM H22
 BACK RAIL HEIGHT 33

SG SW



1071-00 OTTOMAN W31 D21 H17



1074-01 CHAIR

OVERALL W34 D40 H37 SEAT H18
 INSIDE W20 D21 H20 ARM H22
 BACK RAIL HEIGHT 33

SG SW



1074-00 OTTOMAN W31 D21 H17



L1074-01

SW



C1074-01

SG SW



1180-01 CHAIR

OVERALL W34 D40 H39 SEAT H18
 INSIDE W20 D21 H23 ARM H22
 BACK RAIL HEIGHT 34

SG SW



1180-00 OTTOMAN W31 D21 H17



C1180-01

SG SW



3477-01 CHAIR

OVERALL W36 D42 H36 SEAT H18
 INSIDE W24 D22 H18 ARM H22
 BACK RAIL HEIGHT 30

SHOWN WITH OPTIONAL TOPSTITCHING
 ON SEAT AND BACK CUSHION
 SHOWN WITH OPTIONAL BANDING AND JUMBO NAIL HEAD



3477-00 OTTOMAN W31 D21 H17



L3477-01



3752-01 CHAIR

OVERALL W31 D41 H38 SEAT H19
 INSIDE W19 D21 H20 ARM H24
 BACK RAIL HEIGHT 33

SHOWN WITH OPTIONAL SKIRT BANDING

SG SW



3752-00 OTTOMAN W23 D18 H16



C3752-01

SHOWN WITH OPTIONAL SKIRT BANDING

SG SW



3452-01 CHAIR

OVERALL W31 D41 H38 SEAT H19
 INSIDE W19 D21 H20 ARM H24
 BACK RAIL HEIGHT 33



3452-00 OTTOMAN W23 D18 H16



L3452-01



C3452-01

SHOWN WITH OPTIONAL TOPSTITCHING