



5361-01 CHAIR

OVERALL W28 D37 H37 SEAT H19
 INSIDE W22 D21 H19 ARM H25
 SHOWN WITH OPTIONAL TOPSTITCHING

SW



5361-00 OTTOMAN W28 D24 H16



5700-01 CHAIR

OVERALL W35 D36 H35 SEAT H18
 INSIDE W25 D21 H18 ARM H27
 BACK RAIL HEIGHT 27
 STANDARD WITH TOPSTITCHING
 SHOWN WITH SLIPCOVER

SG SW



5700-00 OTTOMAN W27 D21 H16



C5700-01
SG SW



5710-01 CHAIR

OVERALL W33 D38 H36 SEAT H19
 INSIDE W20 D21 H18 ARM H24
 BACK RAIL HEIGHT 31
 STANDARD WITH TOPSTITCHING

SG SW



5710-00 OTTOMAN W27 D21 H16



C5710-01
SG SW



5720-01 CHAIR

OVERALL W28 D38 H36 SEAT H19
 INSIDE W20 D21 H18 ARM H23
 BACK RAIL HEIGHT 31
 STANDARD WITH TOPSTITCHING

SG SW



5720-00 OTTOMAN W27 D21 H16



C5720-01
SG SW



4630-16 CHAIR-AND-A-HALF

OVERALL W55 D48 H31 SEAT H17
 INSIDE W40 D34 H15 ARM H25
 STANDARD WITH TOPSTITCHING
 (2) 23x23 THROW PILLOWS

SW