



3471-01 CHAIR

OVERALL W30 D39 H41 SEAT H18
 INSIDE W22 D19 H24 ARM H25
 STANDARD WITH TOPSTITCHING
 STANDARD WITH DOWN BACK

SW



3471-00 OTTOMAN W27 D21 H15



1401-01 CHAIR

OVERALL W32 D38 H32 SEAT H17
 INSIDE W26 D22 H16 ARM H26
 BACK RAIL HEIGHT 32
 STANDARD WITH TOPSTITCHING ON SEAT AND BACK CUSHION
 STANDARD WITH DOWN BACK

SW



1401-00 OTTOMAN W31 D21 H17



C1401-01

SW



C3071-01 CHAIR

OVERALL W35 D38 H36 SEAT H17
 INSIDE W26 D21 H20 ARM H26
 BACK RAIL HEIGHT 33
 STANDARD WITH FRENCH SEAM
 STANDARD WITH SELF FLANGE ON BACK CUSHION

SW



3221-01 CHAIR

OVERALL W35 D35 H37 SEAT H18
 INSIDE W24 D20 H20 ARM H25
 STANDARD WITH TOPSTITCHING
 SHOWN WITH OPTIONAL FOUR INCH SKIRT BAND

SW



3221-00 OTTOMAN W23 D18 H16



1641-01 CHAIR

OVERALL W31 D32 H32 SEAT H18
 INSIDE W22 D21 H16 ARM H25
 STANDARD WITH TOPSTITCHING

SW



1641-00 OTTOMAN W23 D18 H16



1283-01 CHAIR

OVERALL W30 D37 H33 SEAT H17
 INSIDE W21 D24 H17 ARM H25
 STANDARD WITH TOPSTITCHING

SW



1283-00 OTTOMAN W23 D18 H14



L1283-01

SHOWN WITH OPTIONAL
 CABLESTITCH

SW