



**1571-01SG SWIVEL GLIDER
1571-01SW SWIVEL CHAIR**

OVERALL W35 D38 H35 SEAT H18
INSIDE W25 D22 H18 ARM H22
BACK RAIL HEIGHT 32
STANDARD WITH TOPSTITCHING
SHOWN WITH OPTIONAL WELT



1571-00 OTTOMAN W31 D25 H17



**1071-01SG SWIVEL GLIDER
1071-01SW SWIVEL CHAIR**

OVERALL W34 D40 H37 SEAT H18
INSIDE W20 D21 H20 ARM H22
BACK RAIL HEIGHT 33
SHOWN WITH OPTIONAL SKIRT BANDING



1071-00 OTTOMAN W31 D21 H17



1074-01SW SWIVEL CHAIR

OVERALL W34 D40 H37 SEAT H18
INSIDE W20 D21 H20 ARM H22
BACK RAIL HEIGHT 33



1074-00 OTTOMAN W31 D21 H17



L1074-01SW



C1074-01SG
C1074-01SW



**1180-01SG SWIVEL GLIDER
1180-01SW SWIVEL CHAIR**

OVERALL W34 D40 H39 SEAT H18
INSIDE W20 D21 H23 ARM H22
BACK RAIL HEIGHT 34



1180-00 OTTOMAN W31 D21 H17



C1180-01SG
C1180-01SW



**3752-01SG SWIVEL GLIDER
3752-01SW SWIVEL CHAIR**

OVERALL W31 D41 H38 SEAT H19
INSIDE W19 D21 H20 ARM H24
BACK RAIL HEIGHT 33
SHOWN WITH OPTIONAL SKIRT BANDING



3752-00GO GLIDER OTTOMAN
W21 D21 H16



C3752-01SG
C3752-01SW
SHOWN WITH OPTIONAL
SKIRT BANDING



2360-01SW SWIVEL CHAIR

OVERALL W30 D40 H37 SEAT H19
INSIDE W18 D22 H17 ARM H23
BACK RAIL HEIGHT 33



2360-00 OTTOMAN W23 D18 H16