



**1717-01SG SWIVEL GLIDER  
1717-01SW SWIVEL CHAIR**

OVERALL W27 D33 H35 SEAT H19  
INSIDE W18 D19 H18 ARM H26



C1717-01SG  
C1717-01SW



**1931-01SW SWIVEL CHAIR**

OVERALL W28 D34 H34 SEAT H18  
INSIDE W21 D22 H15 ARM H26  
STANDARD WITH TOPSTITCHING



C1931-01SW



1931-00 OTTOMAN W27 D21 H15



**1391-01SW SWIVEL CHAIR**

OVERALL W29 D33 H36 SEAT H18  
INSIDE W20 D20 H19 ARM H24



1391-00 OTTOMAN W23 D18 H16



**3621-01SW SWIVEL CHAIR**

OVERALL W30 D36 H33 SEAT H18  
INSIDE W24 D22 H16 ARM H25  
STANDARD WITH TOPSTITCHING  
STANDARD WITH DOWN



C3621-01SW



3621-00 OTTOMAN W27 D21 H15



**3821-01SG SWIVEL GLIDER  
3821-01SW SWIVEL CHAIR**

OVERALL W30 D36 H33 SEAT H18  
INSIDE W24 D21 H16 ARM H25  
STANDARD WITH TOPSTITCHING



C3821-01SG  
C3821-01SW



**3471-01SW SWIVEL CHAIR**

OVERALL W30 D39 H41 SEAT H18  
INSIDE W22 D19 H24 ARM H25  
STANDARD WITH TOPSTITCHING  
STANDARD WITH DOWN BACK



3821-00 OTTOMAN W27 D21 H16



3471-00 OTTOMAN W27 D21 H15