



**7071-01SG SWIVEL GLIDER  
7071-01SW SWIVEL CHAIR**

OVERALL W29 D35 H35 SEAT H18  
INSIDE W21 D19 H18 ARM H25  
BACK RAIL HEIGHT 35

STANDARD WITH FRENCH SEAM ON ARMS, BACKS AND CUSHIONS  
STANDARD WITH DOWN BACK



7071-00 OTTOMAN W27 D21 H17



**7073-01SG SWIVEL GLIDER  
7073-01SW SWIVEL CHAIR**

OVERALL W29 D35 H35 SEAT H18  
INSIDE W21 D19 H18 ARM H25  
BACK RAIL HEIGHT 35

STANDARD WITH FRENCH SEAM ON ARMS, BACKS AND CUSHIONS  
STANDARD WITH DOWN BACK



7073-00 OTTOMAN W27 D21 H17



C7073-01SG  
C7073-01SW



**1201-01SW SWIVEL CHAIR**

OVERALL W25 D28 H31 SEAT H18  
INSIDE W18 D18 H14 ARM H23  
BACK RAIL HEIGHT 30

STANDARD WITH TOPSTITCHING  
STANDARD WITH DOWN BACK



**3009-01SW SWIVEL CHAIR**

OVERALL W33 D34 H32 SEAT H16  
INSIDE W24 D22 H15 ARM H28  
STANDARD WITH HAVEN



3009-00 OTTOMAN W23 D18 H16  
OTTOMAN NOT AVAILABLE IN LEATHER



L3009-01SW



C3009-01SW



**5772-01SW SWIVEL CHAIR**

OVERALL W29 D33 H29 SEAT H18  
INSIDE W21 D22 H12 ARM H24  
STANDARD WITH TOPSTITCHING



L5772-01SW



**5027-01SW SWIVEL CHAIR**

OVERALL W34 D31 H30 SEAT H19  
INSIDE W20 D23 H12 ARM H27  
STANDARD WITH TOPSTITCHING



L5027-01SW