



C3293-01SG
C3293-01SW



C5632-01SG
C5632-01SW
C5632-00GO
W27 D21 H16

3293-01SG SWIVEL GLIDER
3293-01SW SWIVEL CHAIR

OVERALL W32 D37 H35 SEAT H19
INSIDE W18 D23 H18 ARM H24
BACK RAIL HEIGHT 31



3293-00GO GLIDER OTTOMAN
W21 D21 H16

5632-01SW SWIVEL CHAIR

OVERALL W34 D38 H37 SEAT H19
INSIDE W20 D22 H19 ARM H24
BACK RAIL HEIGHT 31



5632-00 OTTOMAN W27 D21 H16



C3188-01SG
C3188-01SW



C2450-01SG
C2450-01SW

3188-01SG SWIVEL GLIDER
3188-01SW SWIVEL CHAIR

OVERALL W35 D35 H35 SEAT H18
INSIDE W21 D21 H16 ARM H24
BACK RAIL HEIGHT 28



3188-00 OTTOMAN W26 D22 H16

2450-01SG SWIVEL GLIDER

OVERALL W35 D38 H40 SEAT H20
INSIDE W19 D20 H20 ARM H25
BACK RAIL HEIGHT 35
SHOWN WITH OPTIONAL TOPSTITCHING

2450-01SW SWIVEL CHAIR

OVERALL W35 D38 H38 SEAT H20
INSIDE W19 D20 H18 ARM H25
BACK RAIL HEIGHT 33



2450-00GO GLIDER OTTOMAN
W21 D21 H16



C3794-01SG
C3794-01SW



3794-01SG SWIVEL GLIDER
3794-01SW SWIVEL CHAIR

OVERALL W32 D37 H35 SEAT H18
INSIDE W18 D23 H18 ARM H24
BACK RAIL HEIGHT 31



3794-00GO GLIDER OTTOMAN
W21 D21 H16

3081-01SG SWIVEL GLIDER
3081-01SW SWIVEL CHAIR

OVERALL W36 D37 H36 SEAT H18
INSIDE W21 D20 H18 ARM H23
BACK RAIL HEIGHT 31



3081-00 OTTOMAN W31 D21 H17