



US102-01SG
SWIVEL GLIDER
US102-01SW
SWIVEL CHAIR



US137-01SG
SWIVEL GLIDER
US137-01SW
SWIVEL CHAIR

US102-01 AGAVE OUTDOOR CHAIR

OVERALL W31 D37 H35 SEAT H19
INSIDE W23 D21 H15 ARM H26
BACK RAIL HEIGHT 31
STANDARD WITH BRUSHED ALUMINUM FEET



US102-00 AGAVE OTTOMAN
W25 D22 H16

US137-01 CYPRESS OUTDOOR CHAIR

OVERALL W27 D33 H33 SEAT H17
INSIDE W21 D21 H17 ARM H24
BACK RAIL HEIGHT 29
STANDARD WITH TOPSTITCHING



US137-00 CYPRESS OTTOMAN
W23 D18 H16



US135-01SG SEASIDE OUTDOOR
SWIVEL GLIDER
US135-01SW SEASIDE OUTDOOR
SWIVEL CHAIR

OVERALL W28 D32 H34 SEAT H17
INSIDE W24 D22 H18 ARM H24
BACK RAIL HEIGHT 32
STANDARD WITH TOPSTITCHING



US112-01SG
SWIVEL GLIDER
US112-01SW
SWIVEL CHAIR

US112-01 NANDINA OUTDOOR CHAIR

OVERALL W31 D34 H33 SEAT H17
INSIDE W24 D21 H17 ARM H24
BACK RAIL HEIGHT 33
STANDARD WITH TOPSTITCHING
STANDARD WITH ZIPPER CLOSURE



US112-00 NANDINA OTTOMAN
W23 D18 H14



US127-01 BERMUDA OUTDOOR CHAIR

OVERALL W38 D37 H35 SEAT H18
INSIDE W24 D22 H18 ARM H24
BACK RAIL HEIGHT 28
STANDARD WITH TOPSTITCHING



US127-00 BERMUDA OTTOMAN
W24 D24 H18