



**US116-01 LOTUS
OUTDOOR CHAIR**

OVERALL W32 D37 H38 SEAT H18
INSIDE W25 D21 H19 ARM H24
STANDARD WITH TOPSTITCHING
STANDARD WITH ZIPPER CLOSURE



US116-00 LOTUS OTTOMAN
W31 D21 H17



**US116-01SG
SWIVEL GLIDER
US116-01SW
SWIVEL CHAIR**



**US156-01 ROCKPORT
OUTDOOR CHAIR**

OVERALL W29 D36 H35 SEAT H17
INSIDE W20 D21 H19 ARM H23
BACK RAIL HEIGHT 30
STANDARD WITH TOPSTITCHING



US156-00 ROCKPORT OTTOMAN
W23 D18 H16



**US156-01SG
SWIVEL GLIDER
US156-01SW
SWIVEL CHAIR**
*SHOWN WITH
OPTIONAL BANDING*



**US120-01 CABO LOUNGER
OUTDOOR CHAIR**

OVERALL W30 D40 H36 SEAT H14
INSIDE W21 D21 H22 ARM H20
STANDARD WITH TOPSTITCHING
STANDARD WITH NON-SWIVEL OUTDOOR CASTERS ON FRONT
AND BRUSHED ALUMINUM LEGS ON BACK



US120-00 CABO OTTOMAN
W24 D18 H14
STANDARD WITH BRUSHED ALUMINUM LEGS



**US103-01 SUNSET LOUNGER
OUTDOOR CHAIR**

OVERALL W28 D34 H36 SEAT H16
INSIDE W22 D21 H22 ARM H22
STANDARD WITH TOPSTITCHING



US103-00 SUNSET OTTOMAN
W25 D19 H15



**US103-01SW
SWIVEL CHAIR**



**US104-01C MIMOSA
OUTDOOR CHAIR**

OVERALL W23 D28 H42 SEAT H22
INSIDE W20 D19 H22 ARM H24
STANDARD WITH TOPSTITCHING
STANDARD WITH OUTDOOR CASTERS
AVAILABLE WITHOUT CASTERS



**US144-01C HAMPTON
OUTDOOR CHAIR**

OVERALL W24 D25 H33 SEAT H20
INSIDE W19 D19 H14 ARM H25
BACK RAIL HEIGHT 33
STANDARD WITH TOPSTITCHING
STANDARD WITH OUTDOOR CASTERS