



BACK DETAIL

**U160-17 HAMPTON OUTDOOR  
ARMLESS SOFA**

OVERALL W68 D34 H34 SEAT H17  
 INSIDE W68 D20 H15  
 BACK RAIL HEIGHT 31  
 STANDARD WITH TOPSTITCHING  
 STANDARD WITH CUSHION TIE DOWNS  
 TEAK FRAME



BACK DETAIL



BACK DETAIL



**U160-08 HAMPTON OUTDOOR  
ARMLESS CHAIR**

OVERALL W34 D34 H34 SEAT H17  
 INSIDE W34 D20 H15  
 BACK RAIL HEIGHT 31  
 STANDARD WITH TOPSTITCHING  
 STANDARD WITH CUSHION TIE DOWNS  
 TEAK FRAME

**U160-15 HAMPTON OUTDOOR  
ARMLESS CHAISE**

OVERALL W34 D62 H34 SEAT H17  
 INSIDE W34 D47 H15  
 BACK RAIL HEIGHT 31  
 STANDARD WITH TOPSTITCHING  
 STANDARD WITH CUSHION TIE DOWNS  
 TEAK FRAME



**US1496-01SW  
SWIVEL CHAIR**



**US1496-01 MONTAUK  
OUTDOOR CHAIR**

OVERALL W36 D39 H37 SEAT H18  
 INSIDE W36 D23 H16  
 BACK RAIL HEIGHT 31  
 STANDARD WITH TOPSTITCHING



**U7676-01 TEAK  
SHIN TOASTER CHAIR**

OVERALL W19 D22 H25 SEAT H15  
 INSIDE W19 D15 H11  
 STANDARD WITH SMALL NAIL HEAD  
 NAIL HEAD CANNOT BE OMITTED  
 TEAK FRAME