



US137-01 OUTDOOR CHAIR

OVERALL: W27 D33 H33
SEAT HEIGHT: 17
BACK RAIL HEIGHT: 29

INSIDE: W21 D21 H17
ARM HEIGHT: 24

STANDARD WITH

Topstitching
Cushion - Outdoor