



## US144-01C OUTDOOR DINING CHAIR

OVERALL: W24 D25 H33  
SEAT HEIGHT: 20  
BACK RAIL HEIGHT: 0

INSIDE: W19 D19 H14  
ARM HEIGHT: 25

### STANDARD WITH

Topstitching  
Outdoor Casters  
Cushion - Outdoor

### SHOWN WITH

Optional Contrasting 4-Inch Skirt Band