



## US104-01C MIMOSA OUTDOOR SLIPCOVERED DINING CHAIR

OVERALL: W23 D28 H42  
SEAT HEIGHT: 19  
BACK RAIL HEIGHT: 25

INSIDE: W20 D19 H22  
ARM HEIGHT: 24

### STANDARD WITH

Topstitching  
Outdoor Casters  
Cushion - Outdoor

The casters can be omitted and replaced with 2.5" wooden feet in LEE and Coveralls and 2.25" plastic in Uncovered for no charge.