



US144-01C OUTDOOR DINING CHAIR

OVERALL: W24 D25 H33
SEAT HEIGHT: 20
BACK RAIL HEIGHT: 0

INSIDE: W19 D19 H14
ARM HEIGHT: 25

STANDARD WITH

Topstitching
Outdoor Casters
Cushion - Outdoor

SHOWN WITH

Optional Contrasting 4-Inch Skirt Band