



9820-41 WICKER CHAIR

OVERALL: W26.50 D25 H32
SEAT HEIGHT: 18.50
BACK RAIL HEIGHT: 32

INSIDE: W21 D19.50 H13
ARM HEIGHT: 25

STANDARD WITH
TOPSTITCHING CUSHION - NATURAL LEE