



US102-01 AGAVE OUTDOOR CHAIR

OVERALL W31 D37 H35 SEAT H19
 INSIDE W23 D21 H15 ARM H26
 BACK RAIL HEIGHT 31
 STANDARD WITH BRUSHED ALUMINUM FEET



US102-00 AGAVE OTTOMAN
 W25 D22 H16



US102-01SG SWIVEL GLIDER
US102-01SW SWIVEL CHAIR



US137-01 CYPRESS OUTDOOR CHAIR

OVERALL W27 D33 H33 SEAT H17
 INSIDE W21 D21 H17 ARM H24
 BACK RAIL HEIGHT 29
 STANDARD WITH TOPSTITCHING



US137-00 CYPRESS OTTOMAN
 W23 D18 H16



US137-01SG SWIVEL GLIDER
US137-01SW SWIVEL CHAIR



US135-01SG SEASIDE OUTDOOR SWIVEL GLIDER
US135-01SW SEASIDE OUTDOOR SWIVEL CHAIR

OVERALL W28 D32 H34 SEAT H17
 INSIDE W24 D22 H18 ARM H24
 BACK RAIL HEIGHT 32
 STANDARD WITH TOPSTITCHING



US112-01 NANDINA OUTDOOR CHAIR

OVERALL W31 D34 H33 SEAT H17
 INSIDE W24 D21 H17 ARM H24
 BACK RAIL HEIGHT 33
 STANDARD WITH TOPSTITCHING



US112-00 NANDINA OTTOMAN
 W23 D18 H14



US112-01SG SWIVEL GLIDER
US112-01SW SWIVEL CHAIR



US127-01 BERMUDA OUTDOOR CHAIR

OVERALL W38 D37 H35 SEAT H18
 INSIDE W24 D22 H18 ARM H24
 BACK RAIL HEIGHT 28
 STANDARD WITH TOPSTITCHING



US127-00 BERMUDA OTTOMAN
 W24 D24 H18